



TruVision IP PTZ Camera Configuration Manual

Firmware 5.0X

Copyright	© 2013 UTC Fire & Security Americas Corporation, Inc. Interlogix is part of UTC Climate Controls & Security, a unit of United Technologies Corporation. All rights reserved.
Trademarks and patents	The TruVision and Interlogix names and logos are trademarks of United Technologies. Other trade names used in this document may be trademarks or registered trademarks of the manufacturers or vendors of the respective products.
Manufacturer	UTC Fire & Security Americas Corporation, Inc. 2955 Red Hill Avenue, Costa Mesa, CA 92626-5923, USA Authorized EU manufacturing representative: UTC Fire & Security B.V. Kelvinstraat 7, 6003 DH Weert, The Netherlands
Contact information	For contact information, see www.interlogix.com or www.utcssecurityproducts.eu .
Customer support	www.interlogix.com/customer-support

Content

Chapter 1	Introduction	1
Chapter 2	Network connection	3
	Checking your web browser security level	3
	Configuring IE ActiveX controls	3
	Windows Vista and 7 users	4
	Accessing the camera over the internet	5
	Overview of the camera web browser	5
Chapter 3	Camera configuration	9
	Configuration menu overview	9
	Local configuration	10
	System time	12
	Network settings	13
	Recording parameters	17
	Video image	18
	OSD	21
	Overlay text	22
	ROI encoding of an image	23
	Intelligent tracking	24
	PTZ parameters	25
	PTZ home position	25
	Basic PTZ parameters	25
	Limit camera movement	26
	Schedule tasks	27
	Park actions	29
	Privacy masks	29
	Clear PTZ configurations	31
	Motion detection alarms	31
	Tamper-proof alarms	33
	Exception alarms	34
	Alarm inputs and outputs	35
	Video loss alarms	37
	Snapshot parameters	38
	NAS settings	39
	Format storage devices	40
	Recording schedule	41
Chapter 4	Camera management	45
	User management	45
	Adding and deleting users	46
	Modifying user information	47
	RTSP authentication	47
	IP address filter	48

- Telnet 49
- Restore default settings 49
- Import/export a configuration file 50
- Upgrade firmware 50
- Reboot camera 51

Chapter 5

- Camera operation 53**
 - Logging on and off 53
 - Live view mode 53
 - Playing back recorded video 54
 - Searching event logs 57
 - Operating PTZ control 59
 - PTZ control panel 59
 - Using presets 60
 - Using preset tours 61
 - Using shadow tours 62

Index 63

Chapter 1

Introduction

This is the configuration manual for the following TruVision IP PTZ camera models:

- TVP-1101 (1.3MPX pendant, PAL)
- TVP-3101 (1.3MPX pendant, NTSC)
- TVP-1102 (1.3MPX surface, PAL)
- TVP-3102 (1.3MPX surface, NTSC)
- TVP-1103 (1.3MPX flush, PAL)
- TVP-3103 (1.3MPX flush, NTSC)
- TVP-1104 (2MPX pendant, PAL)
- TVP-3104 (2MPX pendant, NTSC)
- TVP-1105 (2MPX surface, PAL)
- TVP-3105 (2MPX surface, NTSC)
- TVP-1106 (2MPX flush, PAL)
- TVP-3106 (2MPX flush, NTSC)

Chapter 2

Network connection

This manual explains how to configure the camera over the network with a web browser.

TruVision IP PTZ cameras can be configured and controlled using Microsoft Internet Explorer (IE) and other browsers. The procedures described use Microsoft Internet Explorer (IE) web browser.

Checking your web browser security level


When using the web browser interface, you can install ActiveX controls to connect and view video using Internet Explorer. However, you cannot download data, such as video and images due to the increased security measure. Consequently you should check the security level of your PC so that you are able to interact with the cameras over the web and, if necessary, modify the Active X settings.

Configuring IE ActiveX controls

You should confirm the ActiveX settings of your web browser.

To change the web browser's security level:

1. In Internet Explorer click **Internet Options** on the **Tools** menu.
2. On the Security tab, click the zone to which you want to assign a web site under "Select a web content zone to specify its security settings".
3. Click **Custom Level**.



4. Change the **ActiveX controls and plug-ins** options that are signed or marked as safe to **Enable**. Change the **ActiveX controls and plug-ins** options that are unsigned to **Prompt** or **Disable**. Click **OK**.

- or -

Under **Reset Custom Settings**, click the security level for the whole zone in the **Reset To** box, and select **Medium**. Click **Reset**.

Then click **OK** to the Internet Options Security tab window.



5. Click **Apply** in the Internet Options Security tab window.

Windows Vista and 7 users

Internet Explorer for Windows Vista and Windows 7 operating systems have increased security measures to protect your PC from any malicious software being installed.

To have complete functionality of the web browser interface with Windows Vista and Windows 7, do the following:

- Run the Browser interface as an administrator in your workstation

- Add the camera's IP address to your browser's list of trusted sites

To add the camera's IP address to Internet Explorer's list of trusted sites:

1. Open Internet Explorer.
2. Click **Tools**, and then **Internet Options**.
3. Click the **Security** tab, and then select the Trusted sites icon.
4. Click the **Sites** button.
5. Clear the "Require server verification (https:) for all sites in this zone box.
6. Enter the IP address in the "Add this website to the zone" field.
7. Click **Add**, and then click **Close**.
8. Click **OK** in the Internet Options dialog window.
9. Connect to the camera for full browser functionality.

Accessing the camera over the internet

Use the web browser to access and configure the camera over the internet.

It is recommended that you change the administrator password once the setup is complete. Only authorized users should be able to modify camera settings. See "User management" on page 45 for further information.

To access the camera online:

1. In the web browser enter the camera's IP address (default is 192.168.1.70).
Use the tool, *TruVision Device Finder*, enclosed on the CD to find the IP address of the camera.

The Login dialog box appears.

Note: Ensure that the Active X controls are enabled.

2. Enter your user name and password.

User name: admin

Password: 1234

3. Click **Login**. The web browser window appears in live view mode.

Overview of the camera web browser

The camera web browser lets you view, record, and play back recorded videos as well as manage the camera from any PC with Internet access. The browser's easy-to-use controls give you quick access to all camera functions. See Figure 1 on page 6.

If there is more than one camera connected over the network, open a separate web browser window for each individual camera.

Figure 1: Web browser interface



Table 1: Overview of the web browser interface

No.	Name	Description
1.	Live view	Click to view live video.
2.	Playback	Click to play back video.
3.	Log	Click to search for event logs. There are three main types: Alarm, Exception, and Operation.
4.	Configuration	Click to display the configuration window for setting up the camera.
5.	Current user	Displays current user logged on.
6.	Logout	Click to log out from the system. This can be done at any time.
7.	PTZ controls	Direction actions, zoom, focus, iris, light, and wiper control.
8.	Viewer	View live video. Time, date and camera name are displayed here.
9.	Stream type and aspect ratio	Click to select dual or substream and to select the aspect ratio (4x3, 16x9, or x1).
10.	Start/stop live view	Click to start/stop live view.
11.	Audio	Adjust volume.

No.	Name	Description
12.	Bidirectional audio	Turn on/off microphone.
13.	Capture	Click to take a snapshot of the video. The snapshot will be saved to the default folder in JPEG format.
14.	Start/stop recording	Click to record live video.
15.	3D Zoom	Click to enable 3D zoom.
16.	Manual Tracking	Click to enable manual tracking.

Chapter 3

Camera configuration

This chapter explains how to configure the cameras through a web browser.

Once the camera hardware has been installed, configure the camera's settings through the web browser. You must have administrator rights in order to configure the cameras over the internet.

The camera web browser lets you configure the camera remotely using your PC. Web browser options may vary depending on camera model. The camera is configured using on-screen display (OSD) menus.

There are two main folders in the configuration panel:

- Local configuration
- Configuration

Configuration menu overview

Use the **Configuration** panel to configure the server, network, camera, alarms, users, transactions, and other parameters such as upgrading the firmware. See Figure 2 and Table 2 below for descriptions of the configuration folders available.

Figure 2: Configuration panel (Device Information tab of the System folder selected)




Table 2: Overview of the Configuration panel

No.	Configuration folders	Description
1.	System	Defines device basic information including SN and the current firmware version, time settings, and maintenance parameters.
2.	Network	Defines the network parameters required to access the camera over the internet.
3.	Video/Audio	Defines recording parameters.
4.	PTZ	Defines the PTZ parameters.
5.	Image	Defines the image parameters, OSD settings, overlay text, and privacy mask.
6.	Security	Defines who can use the camera, their passwords and access privileges, RTSP authentication, IP address filter, and telnet access.
7.	Events	Defines motion detection, tamper-proof, alarm input/output, exception, and snapshot configuration.
8.	Storage	Defines recording schedule, storage management, and NAS configuration.

Local configuration

Use the Local menu to manage the protocol type, live view performance, and local storage paths. In the Configuration panel, click **Local Configuration** to display the local configuration window. See Figure 3 and Table 3 below for descriptions of the different menu parameters.

Figure 3: Example of a configuration window (Local configuration shown)




Table 3: Overview of the Local configuration window


No.	Parameters	Description
Live View Parameters		
1.	Protocol	Specifies the network protocol used. Options include: TCP, UDP, MULTICAST and HTTP.
2.	Live View Performance	Specifies the transmission speed. Options include: Least Delay, Balanced or Best Fluency.
Record File Settings		
3.	Record File Size	Specifies the maximum file size. Options include: 256 MB, 512 MB and 1G.
4.	Save Record Files to	Specifies the directory for recorded files.
5.	Save Downloaded Files to	Specifies the directory for downloaded files.
Picture and Clip Settings		
6.	Save Snapshots In Live View To	Specifies the directory for saving snapshots in live view mode.
7.	Save Snapshots When Playback To	Specifies the directory for saving snapshots in playback mode.
8.	Save Clips To	Specifies the directory for saving video clips in playback mode.

System time

NTP (Network Time Protocol) is a protocol for synchronizing the clocks of network devices, such as IP cameras and computers. Connecting network devices to a dedicated NTP time server ensures that they are all synchronized.

To define the system time and date:


1. In the **System** folder, click the **Time Settings** (1) tab to open its window.



2. From the **Time Zone** drop-down menu (2), select the time zone that is the closest to the camera's location.
3. Under **Time Sync** (3), check one of the options for setting the time and date:

NTP: Check the **NTP** enable box and enter the server NTP address to synchronize with an NTP server. The time interval can be set from 1 to 10080 minutes.

- Or -

Manual Time Sync.: Enable the **Manual Time Sync** function and then click  to set the system time from the pop-up calendar.

Note: You can also check the **Sync with computer time** checkbox to synchronize the time of the camera with the time of your computer.

4. Check **Enable DST** (4) to enable the DST function, and set the date of the DST period.
5. Click **Save** to save changes.

Network settings

Accessing the camera through a network requires that you define certain network settings. Use the “Network” folder to define the network settings. See Figure 4 and Table 4 below for further information.

Figure 4: Network window (TCP/IP tab shown)




Table 4: Network parameters

No.	Parameters	Description
1.	TCP/IP	<p>NIC Type: Specifies the NIC type. Default is Auto. Other options include: 10M Half-dup, 10M Full-dup, 100M Half-dup and 100M Full-dup.</p> <p>DHCP: Enable to automatically obtain an IP address and other network settings from that server.</p> <p>IPv4 Address: Specifies the IPv4 address of the camera.</p> <p>IPv4 Subnet Mask: Specifies the IPv4 subnet mask.</p> <p>IPv4 Default Gateway: Specifies the IPv4 gateway IP address.</p> <p>IPv6 Mode: Specifies the IPv6 mode, including Manual, DHCP and Router Advertisement.</p> <p>IPv6 Address: Specifies the IPv6 address of the camera.</p> <p>IPv6 Subnet Prefix Length: Specifies the IPv6 prefix length.</p> <p>IPv6 Default Gateway: Specifies the IPv6 gateway IP address.</p> <p>Mac Address: Set to 00:4d:c1:33:11:d4.</p> <p>MTU: Specifies the valid value range of MTU. Default is 1500.</p> <p>Multicast Address: Specifies a D-class IP address between 224.0.0.0 to 239.255.255.255. Only specify this option if you are using the multicast function. Some routers prohibit the use of multicast function in case of a network storm.</p> <p>DNS server: Specifies the DNS server for your network.</p>

No.	Parameters	Description
2.	Port	HTTP Port: Specifies the port used for the Internet Explorer (IE) browser. Default value is 80. RTSP Port: Specifies the RTSP port. The default port number is 554. HTTPS Port: Specifies the HTTPS port. The default port number is 443. SDK Port: Specifies the SDK port. The default port number is 8000.
3.	DDNS	Specifies IP server, DynDNS and ezDDNS.
4.	PPPoE	Use this option to retrieve a dynamic IP address.
5.	SNMP	Enable SNMP to get camera status and parameters related information.
6.	802.1.X	When the feature is enabled, the camera data is secured and user authentication is needed when connecting the camera to the network.
7.	QoS	Enable to solve the network delay and network congestion by configuring the priority of data sending.
8.	UPnP	Specifies the UPnP settings for port mapping.
9.	FTP	Specifies the FTP address and folder to which snapshots of the camera can be uploaded.
10.	Email	Specifies the email address to which messages are sent when an alarm occurs.

To define the TCP/IP parameters:

1. In the **Network** folder, click the **TCP/IP** tab to open its window.
2. Configure the NIC settings, including the NIC Type, IPv4 settings, IPv6 settings, MTU settings, and Multicast Address.
3. If the DHCP server is available, check **DHCP**.
4. If the DNS server settings are required for some applications (e.g., sending email), you should configure the **Preferred DNS Server** or **Alternate DNS Server**.
5. Click **Save** to save changes.

To define the port parameters:

1. In the **Network** folder, click the **Port** tab to open its window.
2. Set the HTTP port, RTSP port, HTTPS port and SDK port of the camera.
3. Click **Save** to save changes.

To define the DDNS parameters:

1. In the **Network** folder, click the **DDNS** tab to open its window.
2. Check **Enable DDNS** to enable this feature.
3. Select **DDNS Type**. Two options are available: DynDNS and IPServer.
 - **DynDNS:** Enter the user name and password registered to the DynDNS web site. The domain name is that of the DynDNS web site.
 - **ezDDNS:** Enter the host name, it will automatically register it online.
 - **IPServer:** Enter the address of the IP Server.

4. Click **Save** to save changes.

To define the PPPoE parameters:

1. In the **Network** folder, click the **PPPoE** tab to open its window.
2. Check **Enable PPPoE** to enable this feature.
3. Enter User Name, Password, and Confirm password for PPPoE access.
4. Click **Save** to save changes.

To define the SNMP parameters:

Note: Before setting the SNMP, please download the SNMP software and manage to receive the camera information via SNMP port. By setting the Trap Address, the camera can send the alarm event and exception messages to the surveillance center. The SNMP version you select should be the same as that of the SNMP software.

1. In the **Network** folder, click the **SNMP** tab to open its window.
2. Select the corresponding version of SNMP: v1, v2c or v3.
3. Configure the SNMP settings. The configuration of the SNMP software should be the same as the settings you configure here.
4. Click **Save** to save changes.

To define the 802.1x parameters:

Note: The switch or router to which the camera is connected must also support the IEEE 802.1X standard, and a server must be configured. Please apply and register a user name and password for 802.1X in the server.

1. In the **Network** folder, click the **802.1X** tab to open its window.
2. Check **Enable IEEE 802.1X** to enable the feature.
3. Configure the 802.1X settings, including EAPOL version, user name, and password. The EAPOL version must be identical with that of the router or the switch.
4. Click **Save** to save changes.

To define the QoS parameters:

1. In the **Network** folder, click the **QoS** tab to open its window.
2. Configure the QoS settings, including Video / Audio DSCP, Event / Alarm DSCP and Management DSCP. The valid value range of the DSCP is 0-63. The bigger the DSCP value is the higher the priority is.
3. Click **Save** to save changes.

To define the FTP parameters:

1. In the **Network** folder click the **FTP** tab to open its window.
2. Configure the FTP settings, including server address, port, user name, password, directory, and upload type.

Directory: In the Directory Structure field, you can select the root directory, main directory and tab. When the main directory is selected, you have the option to use the Device Name, Device Number or Device IP for the name of the directory; and when the tab is selected, you can use the Camera Name or Camera No. as the name of the directory.

Upload type: To enable uploading the snapshots to the FTP server.

3. Click **Save** to save changes.

To define the UPnP parameters:

1. In the **Network** folder click the **UPnP** tab to open its window.
2. Check the checkbox to enable the UPnP function. The name of the device when detected online can be edited.
3. Check the Port Mapping, and select Auto or Manual mode to modify the port number.
4. Click **Save** to save changes.

To set up the Email parameters:

1. In the Network folder, click the **Email** tab to open its window.
2. Configure the following settings:

Sender: The name of the email sender.

Sender's Address: The email address of the sender.

SMTP Server: The SMTP Server IP address or host name.

SMTP Port: The SMTP port. The default is 25.

Enable SSL: Check the checkbox to enable SSL if it is required by the SMTP server.

Attached Image: Check the checkbox of **Attached Image** if you want to send emails with attached alarm images.

Interval: This is the time between two actions of sending attached images.

Authentication: If your email server requires authentication, check this checkbox to use authentication to log in to this server. Enter the login user name and password.

Receiver: The name of the user to be notified.

Receiver's Address: The email address of user to be notified.

3. Click **Save** to save changes.

Recording parameters

You can adjust the video and audio recording parameters to obtain the picture quality and file size best suited to your needs. Figure 5 and Table 5 below list the video and audio recording options you can configure for the camera.

Figure 5: Video/Audio Settings menu (Video tab shown)




Table 5: Video setting parameters

No.	Parameter	Description
1.	Stream Type	Specifies the dual streaming method used. Options include: Main Stream (Normal) and Sub Stream.
2.	Video Type	Specifies the stream type you wish to record. Select Video Stream to record video stream only. Select Video&Audio to record both video and audio streams,
3.	Resolution	Specifies the recording resolution. A higher image resolution provides a higher image quality but also requires a higher bit rate. The resolution options listed depend on the type of camera and on whether main or sub stream is being used. Note: Resolutions can vary depending on the camera model.
4.	Bitrate Type	Specifies whether variable or fixed bit rate is used. Variable produces higher quality results suitable for video downloads and streaming. Default is Constant.
5.	Video Quality	Specifies the quality level of the image. It can be set when variable bit rate is selected. Options include: Lowest, Lower, Medium, Higher, and Highest.

No.	Parameter	Description
6.	Frame Rate	Specifies the frame rate for the selected resolution. The frame rate is the number of video frames that are shown or sent per second. Note: The maximum frame rate depends on the camera model and selected resolution. Please check the camera specifications in its datasheet.
7.	Max bit rate	Specifies the maximum allowed bit rate. A high image resolution requires that a high bit rate must also be selected. Options include: 128, 160, 192, 224, 256, 320, 384, 448, 512, 640, 768, 896, 1024, 1536, 1792, 2048, 3072, 4096, 8192, 16384 and Custom (enter a value manually).
8.	Video Encoding	Specifies the video encoder used.
9.	Profile	Different profile indicates different tools and technologies used in compression. Options include: High Profile, Main Profile and Basic Profile.
10.	I-frame Interval	A video compression method. It is strongly recommended not to change the default value 25.
11.	Audio Encoding	G.711ulaw, G.711alaw and G.726 are optional.

Video image

You may need to adjust the camera image depending on the camera model or location background in order to get the best image quality. You can adjust the brightness, contrast, saturation, hue, and sharpness of the video image. See Figure 6 below.

Use this menu to also adjust camera behavior parameters such as exposure time, iris mode, video standard, day/night mode, image flip, WDR, digital noise reduction, white balance, and indoor/outdoor mode. See Figure 6 and Table 6 below for more information.

Figure 6: Camera image settings menu




Table 6: Image parameters

No.	Parameter	Description
1.	Brightness, Contrast Saturation, Sharpness	Modifies the different elements of picture quality by adjusting the position of the values for each of parameter.
2.	Limit Gain	This feature is used to adjust gain of the image. The value ranges from 0 to 100.
3.	Focus Mode	The Focus Mode can be set to Auto, Manual, and Semi-auto. Auto: The camera focuses automatically at any time according to objects in the scene. Semi-auto: The camera focuses automatically only once after panning, tilting and zooming. Manual: You need to use zoom button on the control panel to focus manually.
4.	Minimum Focusing	This function is used to limit the minimum focus distance. The value can be set to 1.5m, 3m, 6m, 10cm and 50cm.
5.	Exposure Mode	The Exposure Mode can be set to Auto, Iris Priority, Shutter Priority, and Manual. Auto: The iris, shutter and gain values will be adjusted automatically according to the brightness of the environment. Iris Priority: The value of iris needs to be adjusted manually. The shutter and gain values will be adjusted automatically according to the brightness of the environment. Shutter Priority: The value of shutter needs to be adjusted manually. The iris and gain values will be adjusted automatically according to the brightness of the environment. Manual: You can adjust the values of Gain, Shutter, and Iris manually.
6.	Video Standard	The camera cannot auto-sense the power supply. Select 50 Hz (PAL) or 60 Hz (NTSC) depending on your region.

No.	Parameter	Description
7.	Day/Night Switch	<p>Defines whether the camera is in day or night mode. The day (color) option could be used, for example, if the camera is located indoors where light levels are always good.</p> <p>Options:</p> <p>Day: Camera is always in day mode.</p> <p>Night: Camera is always in night mode.</p> <p>Auto: The camera automatically detects which mode to use. Default is Auto.</p>
8.	Sensitivity	<p>Adjusts the sensitivity of the camera from night to day.</p> <p>Options: Low, Normal or High. Default is Normal.</p>
9.	Mirror	<p>Use this function to flip the original image into a mirror image. The image can be flipped centered. Default is Close.</p> <p>Note: The on-screen text does not flip.</p>
10.	DWDR	<p>When enabled, this feature allows you to see details of objects in shadows or details of objects in bright areas of frames that have high contrast between light and dark areas.</p> <p>Note: DWDR is not the real WDR.</p>
11.	Wide Dynamic Level	Adjusts the DWDR level. Set a high value if the backlight is too strong.
12.	Lens Initialization	The lens operates the movements for initialization when you check the check box of Lens Initialization.
13.	White Balance	<p>White balance (WB) tells the camera what the color white looks like. Based on this information, the camera will then continue to display all colors correctly even when the color temperature of the scene changes such as from daylight to fluorescent lighting, for example. Select one of the options:</p> <p>Auto: White balance is determined automatically.</p> <p>Outdoor: Apply for outdoor environments.</p> <p>Indoor: Apply for indoor environments.</p> <p>MWB: You can adjust the color temperature manually to meet your own demand.</p> <p>Fluorescent Lamp: Apply for scene where there are fluorescent lamps installed near the camera.</p> <p>Sodium Lamp: Apply for scene where there are incandescent lamp near the camera.</p> <p>Auto-track: White balance is continuously being adjusted in real-time according to the color temperature of the scene illumination</p> <p>Note: Options can vary depending on the camera models.</p>
14.	Digital Noise Reduction	DNR reduces noise especially in low light conditions to improve image performance.
15.	Noise Reduction Level	Set the level of noise reduction in the Normal Mode. Higher value has a stronger noise reduction.
16.	Zoom Limit	Set Zoom Limit value to limit the maximum value of zooming. The value can be set to 20, 40, 80, 160 and 320.
17.	Chroma Suppress	Adjust this value to control the color especially in low night scene.


No.	Parameter	Description
18.	Local Output	When enabled, the BNC output can display image.

Note: Not all models support all these parameter settings.

OSD

In addition to the camera name, the camera also displays the system date and time on screen. You can also define how the text appears on screen.

Figure 7: OSD settings menu



To position the date/time and name on screen:

1. In the **Image** folder (1), click the **OSD Settings** tab (2) to open its window.
2. Check the **Display Name** (3) box to display the camera's name on screen. You can modify the default name in the text box of **Camera Name**.
3. Check the **Display Date** box (3) to display the date/time on screen.
4. Check the **Display Week** box (3) to include the day of the week in the on-screen display.
5. Select the time format from the **Time format** list box (4).
6. Select the date format from the **Date format** list box (4).
7. Select a display mode for the camera from the **Display Mode** list box (5). Display modes include:
 - **Transparent & Not flickering.** The image appears through the text.


- **Transparent & Flickering.** The image appears through the text. The text flashes on and off.
 - **Not transparent & Not flickering.** The image is behind the text. This is default.
 - **Not transparent & Flickering.** The image is behind the text. The text flashes on and off.
8. Select the OSD size that you want.
 9. Click **Save** to save changes.

Note: If you set the display mode as transparent, the text varies according the scenery. With some sceneries, the text may be not clear.

Overlay text

You can add up to four lines of text on screen. This option can be used, for example, to display emergency contact details. Each text line can be positioned anywhere on screen. See Figure 8 below.

Figure 8: Text overlay menu



To add on-screen text:

1. In the **Image** folder (1), click the **Text Overlay** tab (2) to open its window.
2. Check the box for the first line of text.
3. Enter the text in the text box.
4. Use the mouse to click and drag the red text in the live view window to adjust the text overlay position.

5. Repeat steps 2 to 4 for each extra line of text, selecting the next string number.
6. Click **Save** to save changes.


ROI encoding of an image

This feature helps you to optimize image bandwidth and storage. You can select an important area of detail or ROI (Region of interest) in a stream, such as a number plate or face. The ROI area will have a higher quality image and the non-ROI areas will have a lower image quality thereby saving bandwidth.

You can define up to eight ROIs.

To define an ROI:

1. In the **Video/Audio** folder (1), click the **ROI** tab (2) to open its window.



2. Using the PTZ panel (3), move the lens to the desired location.
3. Select the stream type (4): main stream or substream.
4. Enable **Fixed Region** (5). This lets you manually configure the image quality enhancement level as well as name the region.
5. Select the region number and enhancement level. Enter the region's name.
6. Draw an area in the image.


7. Enable **Dynamic Tracking** (6), if required. This is an intelligent analysis feature that facilitates in face recognition.
8. Repeat steps 2 to 7 to set other regions. Up to eight regions can be set.
9. Click **Save** to save changes.

Intelligent tracking

Intelligent tracking is used to track a moving object or person in a selected region.

To define intelligent tracking:

1. In the **PTZ** folder (1), click the **Intelligent Tracking** tab (2) to open its window.



2. Click **Enable Intelligent Tracking** (3).
3. Set the duration time.
4. Set the zoom ratio (4). This is the zoom level used when you start to track the person or object.
5. Click **Save** to save changes.

PTZ parameters

The following sections explain how to configure the different PTZ parameters.

PTZ home position

The initial position is the PTZ home coordinates. It can be the factory default position or you can customize the initial position to your own requirements.

To set the initial position:

1. In the PTZ folder, click the **Initial Position** tab to open its window.
2. Click the PTZ control buttons to find a position as the initial position of the camera. You can also call a defined preset and set it as the initial position.
3. Click **Set** to save the position.

To call and delete the initial position:


Click **Goto** to call the initial position. Click **Clear** to delete the initial position and restore the factory default initial position.

Basic PTZ parameters

You can configure the basic PTZ parameters, such as proportional pan, preset freezing, preset speed, keyboard control speed, auto scan speed, and PTZ OSD.

To define basic PTZ parameters:

1. In the PTZ folder (1), click the **Basic** tab (2) to open its window.



2. Configure the following settings:

Proportional pan: If you enable this function, the pan/tilt speeds change according to the amount of zoom. When there is a large amount of zoom, the

pan/tilt speed will be slower for keeping the image from moving too fast on the live view image.

Preset freezing: This function enables the live view to switch directly from one scene defined by a preset to another, without showing the middle areas between these two, to ensure the surveillance efficiency. It can also reduce the use of bandwidth in a digital network system.

Note: Preset freezing function is invalid when you calling a pattern.

Preset speed: You can set the speed of a defined preset from 1 to 8.

Keyboard control speed: Define the speed of PTZ control by a keyboard as Low, Normal or High.

Auto scan speed: The camera provides 5 scan modes: auto scan, tilt scan, frame scan, random scan and panorama scan. The scan speed can be set from level 1 to 40.

PTZ OSD: Set the on-screen display duration of the PTZ status.

Zoom status: Set the OSD duration of zooming status as 2 seconds, 5 seconds, 10 seconds, Always Close, or Always Open.

PT status: Set the azimuth angle display duration while panning and tilting as 2 seconds, 5 seconds, 10 seconds, Always Close, or Always Open.

Preset status: Set the preset name display duration while calling the preset as 2 seconds, 5 seconds, 10 seconds, Always Close, or Always Open.

Power-off memory: The dome resumes its previous PTZ status or actions after it restarts from a power-off. You can set the time point of which the dome resumes its PTZ status. You can set it to resume the status of 30 seconds, 60 seconds, 300 seconds, or 600 seconds before power-off.


3. Click **Save** to save changes.

Limit camera movement

The camera can be programmed to move only within a defined area. It is limited in how much it can move left/right and up/down. This can be useful when you do not want an area, such as a neighboring building, to be included in the camera view.

To define the limit stop parameters:

1. In the **PTZ** folder (1), click the **Limit** tab (2) to open its window.



2. Click the Enable Limit checkbox (3) and choose the limit type:

Manual Stops: When manual limit stops are set, you can operate the PTZ control panel manually only within the restricted surveillance area.

Scan Stops: When scan limit stops are set, the random scan, frame scan, auto scan, tilt scan, panorama scan are performed only within the restricted surveillance area.

Note: Manual Stops has priority over Scan Stops. If these two functions are set at the same time, only Manual Stops is enabled.


3. Click the PTZ control buttons to find the left/right/up/down limit stops. You can also call the defined presets and set them as the limits of the camera.
4. Click **Set** to save the limits or click **Clear** to clear the limits.
5. Click **Save** to save changes.

Schedule tasks


You can configure the network camera to perform a certain action automatically during a user-defined time period.

To define a schedule task:

1. In the PTZ folder (1), click the **Schedule Tasks** tab (2) to open its window.



2. Check the checkbox of **Enable Scheduled Task** (3).
3. Set the **Dwell Time** (4). You can set the dwell time in seconds (a period of inactivity) before the camera starts the scheduled tasks.
4. Set the schedule and task details. Click **Edit Tasks** (5) to set the task schedule. The Timing Tasks window appears:



Select **All Day** to set the schedule as all day, or **Customize** and input the start and end times for each task. Click **Enter** on your keyboard to enter the time.

- Choose the task type from the drop-down list. You can choose scan, preset, preset tour, etc.
- Click **Save** (6) to save changes.


Park actions

This is the action that will run automatically after the dwell time. A park action can be, for example, a scan, preset, preset tour, or a shadow tour.

Note: The Scheduled Tasks function (see page 27) has priority over the Park Action function. If these two functions are set at the same time, only Scheduled Tasks is enabled.

To define a park action:

- In the **PTZ** folder (1), click the **Park Action** tab (2) to open its window.



- Check the **Enable Park Action** checkbox (3).
- Set the **Dwell Time**, which is the inactivity time of the dome before it starts the park actions.
- Select an action from the **Action Type** drop-down list (4).
- Click **Save** (5) to save changes.


Privacy masks

Privacy masks let you conceal sensitive areas (such as neighboring windows) to protect them from view on the monitor screen and in the recorded video. The masking appears as a blank area on screen. You can create up to four privacy masks per camera.

Note: There may be a small difference in size of the privacy mask area depending on whether local output or the web browser is used.

To add privacy mask area:

1. In the PTZ folder (1), click the Privacy Mask tab (2) to open its window.



2. Check the **Enable Privacy Mask** (3).
3. Click the PTZ control buttons to point the camera at the area where you want to set the privacy mask. Click **Draw Area** (4).
4. Click and drag the mouse in the live video window to draw the mask area.
5. Click **Stop Drawing** to finish drawing, or click **Clear All** to clear all of the areas you set without saving them.
6. Click **Add** (5) to add the area. Enter its name, color, and active zoom ratio. Each mask can be individually set.

No.	Name	Type	Enable	Active Zoom Ratio
1	Privacy Mask 1	gray	Yes	1
2	Privacy Mask 2	gray	Yes	1
3	Privacy Mask 3	gray	Yes	1
4	Privacy Mask 4	gray	Yes	1

Note: The active zoom ratio is the magnification level the camera will zoom into when motion is detected.


7. Click **Save** to save changes.

Clear PTZ configurations

Use the PTZ configurations menu to clear all presets, preset tours, shadow tours, privacy masks, PTZ limits, scheduled tasks, and park actions.

To clear PTZ configurations:

1. In the PTZ folder (1), click the **Clear Config** tab (2) to open its window.



2. Check the checkbox of the items (3) you want to clear.
3. Click **Save** (4) to save changes.

Motion detection alarms

You can define motion detection alarms. A motion detection alarm refers to an alarm triggered when the camera detects motion. However, the motion alarm is only triggered if it occurs during a programmed time schedule.

Select the level of sensitivity to motion as well as the target size so that only objects that could be of interest can trigger a motion recording. For example, the motion recording is triggered by the movement of a person but not that of a cat.

You can define the area on screen where the motion is detected, the level of sensitivity to motion, the schedule when the camera is sensitive to detecting motion as well as which methods are used to alert you to a motion detection alarm.

You can also enable dynamic analysis for motion. When there is motion, the area will be highlighted in green.


Defining a motion detection alarm requires the following tasks:

1. **Area Settings:** Define the on-screen area that can trigger a motion detection alarm as well as the detection sensitivity level.
2. **Arming Schedule:** Define the schedule which the system detects motion.

3. **Recording schedule:** Define the schedule when motion detection can be recorded. See “Recording schedule” on page 41 for further information.
4. **Linkage:** Specify the method of response to the alarm.

To set up motion detection:


1. In the **Events** folder (1), click the **Motion Detection** tab (2) to open its window.




2. Check the **Enable Motion Detection** box (3). Check **Enable dynamic analysis for motion** if you want to see in live view where the detected motion has occurred.

Note: Deselect the “Enable Motion Detection” option to disable the motion detection alarm.

3. Click **Draw Area** (4). Click and drag the mouse on the live video image to draw an area sensitive to motion detection.
Note: You can draw up to eight motion detection areas on the same image.
4. Click **Stop Drawing** to finish drawing. Click **Clear All** to delete all areas marked and restart drawing.
5. Move the **Sensitivity** slider (5) to set the sensitivity of the detection. All areas will have the same sensitivity level.
6. Click **Edit** to edit the arming schedule. The Edit Schedule Time window opens:



7. Select the day and click  to set the start and end time periods. You can copy the schedule to other days or to the whole week.
8. Click **OK** to save changes.
9. Specify the linkage method when an event occurs. Check one or more response methods for the system when a motion detection alarm is triggered.

Notify Alarm Host	Send an exception or alarm signal to remote management software when an event occurs.
Send Email	Sends an email to a specified address when there is a motion detection alarm.
Upload Snapshot	Capture the image when an alarm is triggered and upload the picture to NAS or FTP server.
Trigger Channel	Triggers the recording to start in the camera.
Trigger Alarm Output	Trigger external alarm outputs when an event occurs. Note: This option is only supported by cameras that support alarm output.


10. Click **Save** to save changes.

Tamper-proof alarms

You can configure the camera to trigger an alarm when the lens is covered and to take an alarm response action.

To set up tamper-proof alarms:

1. In the **Events** folder (1), click the **Tamper-proof** tab (2) to open its window.



2. Check the **Enable Tamper-proof** box (3).
3. Click **Draw Area** (4). Click and drag the mouse on the live video image to draw a tamper-proof area.
4. Click **Stop Drawing** to finish drawing. Click **Clear All** to delete all areas marked and restart drawing.
5. Move the **Sensitivity** slider to set the sensitivity of the detection.
All areas will have the same sensitivity level.
6. Click **Edit** to edit the arming schedule for tamper-proof alarms. The arming schedule configuration is the same as that for motion detection. See “To set up motion detection” for more information.
7. Check the checkbox to select the linkage method taken for the tamper-proof.
8. Click **Save** to save changes.


Exception alarms

You can set up the camera to notify you when irregular events occur and how you should be notified. These exception alarms include:

- **HDD Full:** All recording space of NAS is full.
- **HDD Error:** Errors occurred while files were being written to the storage, no storage or storage had failed to initialize.
- **Network Disconnected:** Disconnected network cable.
- **IP Address Conflicted:** Conflict in IP address setting.
- **Illegal Login:** Wrong user ID or password used to login to the cameras.

To define exception alarms:

1. In the **Events** folder (1), click the **Exception** tab (2) to open its window.




2. Under **Notification Type** (3), select one of the exception alarms from the drop-down list.
3. Check the checkbox to select the linkage method (4): Notify alarm host, send email, or trigger alarm output. If “Trigger alarm output” is selected, check which type is required: Select all, A->1, or A>2.
4. Repeat steps 2 and 3 for each of the exception alarms to be configured.
5. Click **Save** (5) to save changes.

Alarm inputs and outputs

To define an external alarm input:


1. In the **Events** folder (1), click the **Alarm Input** tab (2) to open its window.



2. Choose the **Alarm Input No.** and the **Alarm Type** (3). The alarm type can be NO (Normally Open) or NC (Normally Closed). Enter a name for the alarm input.
3. Click **Edit** (4) to set the arming schedule for the alarm input. See “Motion detection alarms” on page 31 for more information.
4. Check the checkbox to select the linkage method.
5. Click **Save** to save changes.

To define an alarm output:

1. In the **Events** folder (1), click the **Alarm Output** (2) tab to open its window.




2. Select one alarm output channel from the **Alarm Output** drop-down list (3). You can also set a name for the alarm output.
3. The delay time can be set to 5sec, 10sec, 30sec, 1min, 2min, 5min or 10min. The delay time refers to the time duration that the alarm output remains in effect after alarm occurs.
4. Click **Edit** (4) to set the arming schedule for the alarm input. See “To set up motion detection” for more information.
5. Click **Save** to save changes.

Video loss alarms

To define video loss alarm:

1. In the **Events** folder (1), click the **Video Loss** tab (2) to open its window.
2. Check the **Enable Video Loss Detection** checkbox (3) to enable the video loss detection.



3. Click **Edit** (4) to set the arming schedule for the video loss alarm. See “To set up motion detection” for more information.
4. Check the checkbox to select the linkage method.
5. Click **Save** to save changes.


Snapshot parameters

You can configure scheduled snapshots and event-triggered snapshots. The captured snapshots can be stored in the SD card (if supported) or the NAS. You can also upload the snapshots to an FTP server.

Note: If you have configured the FTP settings and check **Upload Picture** in the FTP tab, the snapshots will be uploaded to the FTP. If you also check **Upload Snapshot** for motion detection or alarm input, the snapshots will be uploaded to the FTP when motion detection or an alarm input is triggered.

To set up snapshots:

1. In the **Events** folder (1), click the **Snapshot** tab (2) to open its window.



2. Check **Enable Timing Snapshot** (3) to enable continuous snapshots. Check the **Enable Event-triggered Snapshot** (4) to enable event-triggered snapshots.
3. Select the desired quality of the snapshot.
4. Set the time interval between two snapshots.
5. Click **Save** (5) to save changes.

NAS settings


You can use a network storage system (NAS) to remotely store recordings. To configure record settings, please ensure that you have the network storage device within the network.

The NAS disk should be available within the network and correctly configured to store the recorded files, log files, etc.

Notes: Up to eight NAS disks can be connected to the camera.

To set up a NAS system:

1. In the **Storage** folder (1), click the **NAS** tab (2) to open its window.



2. Enter the IP address of the network disk, (3) and the NAS folder path.
3. Click **Save** (4) to save changes.

Format storage devices


Use the storage management window to display the capacity, free space available, and the working status of the HDD of the NAS and the SD card in the camera. You can also format these storage devices.

Before formatting the storage device, stop all recording. Once formatting is completed, reboot the camera as otherwise the device will not function properly.

If Overwrite is enabled, the oldest files are overwritten when the storage becomes full.

To format the storage devices:

1. In the **Storage** folder (1), click the **Storage Management** tab (2) to open its window.



2. Check the **HDD Number** column to select the storage.
3. Click **Format**. A window appears to check your formatting permission.

4. Click **OK** to start formatting.

Recording schedule

You can define a recording schedule for the camera in the “Record Schedule” window. The recording is saved on to the SD card or NAS in the camera. The camera’s SD card provides a backup in case of network failure.

The selected recording schedule applies to all alarm types.

Pre-record time

The pre-record time is set to start recording before the scheduled time or the event. For example, if an alarm triggers recording at 10:00, and the pre-record time is set as 5 seconds, the camera starts to record at 9:59:55. The pre-record time can be configured as No Pre-record, 5 s, 10 s, 15 s, 20 s, 25 s, 30 s, or not limited.

Post-record time


The post-record time is set to stop recording after the scheduled time or the event. For example, if an alarm triggered recording ends at 11:00, and the post-record time is set as 5 seconds, the camera records until 11:00:05. The post-record time can be configured as 5 s, 10 s, 30 s, 1 min, 2 min, 5 min, or 10 min.

To set up a recording schedule:

1. In the **Storage** folder, click the **Record Schedule** tab to open its window.
2. Click the **Enable Record Schedule** box to enable recording.

Note: To disable recording, deselect the option.

3. Click **Edit** to edit the recording schedule. The following window appears:



4. Select whether the recording will be for the whole week (**All Day** recording) or for specific days of the week.

If you have selected “All Day” (1), select one of the record types to record from the drop-down list box:

- **Normal:** This is continuous recording.
- **Motion detection:** The video is recorded when the motion is detected.
- **Alarm:** The video is recorded when the alarm is triggered via the external alarm input.
- **Motion | Alarm:** The video is recorded when the external alarm is triggered or the motion is detected.
- **Motion & Alarm:** The video is recorded when motion and alarms are triggered at the same time.

5. If you selected “Customize” (2), click the day of the week required and then for period 1 set the start and end times during which you want the camera to begin and end recording.

From the drop-down list box, select one of the record types to record.

Repeat for additional periods in the day. Up to four time periods can be selected.

Note: The time periods cannot overlap.

6. Set the recording periods for the other days of the week if required.

Click **Copy** (3) to copy the recording periods to another day of the week.

7. Click **OK** and **Save** (4) to save changes.

Note: If you set the record type to “Motion detection” or “Alarm”, you must also define the arming schedule in order to trigger motion detection or alarm input recording.

Chapter 4

Camera management

This chapter describes how to use the camera once it is installed and configured. The camera is accessed through a web browser.


User management

This section describes how to manage users. You can:

- Add or delete users
- Modify permission
- Modify passwords

Only the administrator can manage users. The administrator can create up to 31 individual users. When new users are added to the list, the administrator can modify permissions and password of each user. See Figure 9 below.

Figure 9: User management window



Passwords limit access to the camera and the same password can be used by several users. When creating a new user, you must give the user a password. There is no default password provided for all users. Users can not modify their password, and only the administrator can create or modify password for a user.

Note: Keep the admin password in a safe place. If you forget it, please contact technical support.

Types of users

A user's access privileges to the system are automatically defined by their user type. There are three types of user:

- **Admin:** This is the system administrator. The administrator can configure all settings. Only the administrator can create and delete user accounts. Admin cannot be deleted.
- **Operator:** This user can only change the configuration of his/her own account. An operator cannot create or delete other users.
- **Viewer:** This user has the permission of live view, playback and log search. However, they cannot change any configuration settings.

Adding and deleting users

The administrator can create up to 15 users. Only the system administrator can create or delete users.

To add a user:

1. In the **Security** folder, click the **User** tab to open its window.
2. Select the **Add** button. The user management window appears.

3. Enter a user name (1). The name can have up to 16 alphanumeric characters.
4. Select the type of user (2) from the drop-down list. The options are Viewer and Operator.
5. Assign the user a password (3). Passwords can have up to 16 alphanumeric characters.
6. Assign permissions to users (4).

Basic permissions	Camera permissions
Remote parameter settings	Remote live view
Remote log search/Interrogate working status	Remote PTZ control
Remote upgrade/format	Remote manual recording
Remote shutdown/reboot	Remote playback
Remote notify alarm host/Trigger alarm output	
Remote video output control	
Remote serial port control	

7. Click **OK** to save changes.

To delete a user:

1. Select one user in the **User** tab.
2. Click **Delete** button. A message box appears.
Note: Only the administrator can delete a user.
3. Click **Save** to save the changes.

Modifying user information

You can easily change the information about a user such as their name, password and permissions.

To modify user information:


1. Select a user in the **User** tab.
2. Click the **Modify** button. The user management window appears
3. Change the information required.
Note: The user "Admin" can only be changed by entering the admin password.
4. Click **Save** to save changes.

RTSP authentication

You can secure the stream data of live view.

To define RTSP authentication:

1. In the **Storage** folder, click the **Record Schedule** tab to open its window.




2. Select the **Authentication** type **Enable** or **Disable** in the drop-down list to enable or disable the RTSP authentication.
3. Click **Save** to save the changes.

Note: If "RTSP Authentication" is disabled, although the user has no permission for "Remote Live View", he can still see live view images

IP address filter


This function makes it possible for access control.



To define an IP address filter:

1. In the **Security** folder, click the **IP Address Filter** tab to open its window.
2. Check the **Enable IP Address Filter** checkbox.
3. Select the type of IP address filter in the drop-down list, **Forbidden** or **Allowed**.
4. Click **Add** to add an IP address.
5. Click **Modify** or **Delete** to modify or delete the selected IP address.
6. Click **Clear** to delete all the IP addresses.
7. Click **Save** to save changes.

Telnet

**To define Telnet:**

1. In the **Configuration** folder, select the **Security** folder.
2. Select the **Telnet** tab.
3. Check the checkbox of **Enable Telnet**.
4. Click **Save** to save changes.

Restore default settings

Use the Default menu to restore default settings to the camera. There are two options available:

- **Restore:** Restore all the parameters, except the IP parameters, to the default settings.
- **Default:** Restore all the parameters to the default settings.

Note: Video standard cannot be restored to default settings no matter **Restore** or **Default**.

To restore default settings:

1. In the **Configuration** folder, select the **System** tab.
2. Select the **Maintenance** tab.
3. Click either **Restore** or **Default**. A window showing user authentication appears.
4. Enter the admin password and click **OK**.
5. Click **OK** in the pop-up message box to confirm restoring operation.

Import/export a configuration file

To import/export configuration file:

1. In the **Configuration** folder, select the **System** tab.
2. Select the **Maintenance** tab.
3. Click **Browse** to select the local configuration file and then click **Import** to start importing configuration file.
4. Click **Export** and set the saving path to save the configuration file.

Upgrade firmware

The camera firmware is stored in the flash memory. Use the upgrade function to write the firmware file into the flash memory.

You need to upgrade firmware when it has become outdated. When you upgrade the firmware, all existing settings are unchanged. Only the new features are added with their default settings.

To upgrade the firmware through the web browser:

1. Download on to your computer the latest firmware from our web site at:
www.interlogix.com/video/product/truvision-ip-open-standards-outdoor-cameras/
- Or -
www.utcssecurityproductspages.eu/videoupgrades/
2. In the **Configuration** folder, select the **System** tab.
3. Select the **Maintenance** tab.
4. Click the **Browse** button to locate the latest file on your computer.

5. Click **Update**. You will receive a prompt asking you to reboot the camera.

Reboot camera

The camera can be easily rebooted remotely.

To reboot the camera through the web browser:

1. In the **Configuration** folder select the **System** tab.
2. Select the **Maintenance** tab.
3. Click the **Reboot** button to reboot the device.
4. Click **OK** in the pop-up message box to confirm reboot operation.

Chapter 5


Camera operation

This chapter describes how to use the camera once it is installed and configured.

Logging on and off

You can easily log out of the camera browser window by clicking the Logout button on the menu toolbar. You will be asked each time to enter your user name and password when logging in.



Figure 10: Login dialog box



The screenshot shows a login dialog box for the TruVision IP PTZ camera. The interface is dark-themed. At the top left, there is a logo consisting of a camera icon and the text 'truVision IP PTZ'. At the top right, there is a language dropdown menu currently set to 'English'. Below the header, there are two input fields: 'User Name' and 'Password'. A 'Login' button is positioned below the password field.

Live view mode

Once logged in, click “Live View” on the menu toolbar to access live view mode. See Figure 1 on page 6 for the description of the interface.

-  **Start/stop live view:** You can stop and start live view by clicking the Start/stop live view button on the bottom of the window.
-  **Record:** You can record live video and stored it in the directory you have configured. In the live view window, click the **Record** button at the bottom of the window. To stop recording, click the button again.



Take a snapshot: You can take a snapshot of a scene when in live view. Simply click the **Capture** button located at the bottom of the window to save an image. The image is in JPEG format. Snapshots are saved on the hard drive.



3D position: Click to track and zoom out any suspected objects by simply dragging and clicking the mouse.


Playing back recorded video






You can easily search and play back recorded video in the playback interface.



Note: You must configure NAS or insert SD card in the dome camera to be able to use the playback functions.

To search recorded video stored on the camera's storage device for playback, click **Playback** on the menu toolbar. The Playback window displays. See Figure 11 on page 55.

Figure 11: Playback window




No.	Name	Description
1.	Playback button	Click to open the Playback window.
2.	Search calendar	Click the day required to search.
3.	Search	Start search.
4.	Set playback time	Input the time and click  to locate the playback point.
5.	Control playback	Click to control how the selected file is played back: play, stop, slow and fast forward playback.
6.	Timeline bar	The timeline bar displays the 24-hour period of the day being played back. It moves left (oldest) to right (newest). The bar is color-coded to display the type of recording. Click a location on the timeline to move the cursor to where you want playback to start. The timeline can also be scrolled to earlier or later periods for play back. Click   to zoom out/in the timeline bar.
7.	Time moment	Vertical bar shows where you are in the playback recording. The current time and date are also displayed.
8.	Download functions	 Download video files.  Download captured images.

No.	Name	Description
9.	Recording type	The color code displays the recording type. Recording types are schedule recording, alarms recording and manual recording. The recording type name is also displayed in the current status window.
10.	Archive functions	Click these buttons for the following archive actions:  Capture a snapshot image of the playback video.  Start/Stop clipping video files.


To play back recorded video

1. Select the date and click the **Search** button. The searched video is displayed in the timeline.
2. Click **Play** to start playback. While playing back a video, the timeline bar displays the type and time of the recording. The timeline can be manually scrolled using the mouse.


Note: You must have playback permission to playback recorded images. See “Modifying user information” on page 47 to archive recorded video files.


3. Select the date and click the **Search** button to search for the required recorded file.
4. Click  to search the video file.
5. In the pop-up window, check the box of the video file and click **Download** to download the video files.

To archive a recorded video segment during playback:

1. While playing back a recorded file, click  to start clipping. Click it again to stop clipping. A video segment is created.
2. Repeat step 1 to create additional segments. The video segments are saved on your computer.

To archive recorded snapshots:

1. In playback, click  to open the snapshots search window.



2. Select the snapshot type (1) as well as the start and end time (2).
3. Click **Search** (3) to search for the snapshots.
4. Select the desired snapshots, and click **Download** (3) to download them.


Searching event logs

You must configure NAS or insert a SD card in the dome camera to be able to use the log functions.

The number of event logs that can be stored on NAS or SD card depends on the capacity of the storage devices. When this capacity is reached, the system starts deleting older logs. To view logs stored on storage devices, click **Log** on the menu toolbar. The Log window appears. See Figure 12 on page 58.

Note: You must have view log access rights to search and view logs. See “Modifying user information” on page 47 for more information.

Figure 12: Log window



- 1. Major Type
- 2. Minor Type
- 3. Start and end search time
- 4. Start search
- 5. Save searched logs

You can search for recorded logs by the following criteria:

Major type: There are three types of logs: Alarm, Exception, and Operation. You can also search All. See Table 7 below for their descriptions.

Minor type: Each major type has some minor types. See Table 7 below for their descriptions.

Date and Time: Logs can be searched by start and end recording time.

Table 7: Types of logs

Log type	Description of events included
Alarm	Alarm Input, Alarm output, Start Motion Detection, Stop Motion Detection, Start Tamper-proof, Stop Tamper-proof
Exception	Video Signal Loss, Illegal Login, HDD Full, HDD Error, Network Disconnected and IP Address Conflicted
Operation	Power On, Abnormal Shutdown, Remote Reboot, Remote Login, Remote Logout, Remote Configure parameters, Remote Upgrade, Remote Start Record, Remote Stop Record, Remote PTZ Control, Remote Playback by File, Remote Playback by Time, Remote Get Parameters, Remote Get Working Status, Start Bidirectional Audio, Stop Bidirectional Audio, Remote Alarm Arming, Remote Alarm Disarming

To search logs:

1. Click **Log** in the menu toolbar to display the Log window.
2. In the Major Type and Minor Type drop-down list, select the desired option.
3. Select start and end time of the log.
4. Click **Search** to start your search. The results appear in the left window.

Operating PTZ control

In live view you can use the PTZ control buttons to control pan/tilt/zoom and carry out other functions of the camera.

PTZ control panel



In live view, click  /  to display/hide the PTZ control panel.

Figure 13: PTZ control panel




Table 8: Description of the PTZ control panel

No.	Description
1.	Directional buttons: Controls the movements and directions of the PTZ. Center button is used to start auto-pan by the PTZ dome camera.
2.	Zoom, focus and iris: Adjusts zoom, focus and iris.
3.	PTZ movement: Adjusts the speed of PTZ movement.
4.	Turns on/off the light, it is supported by those have RS-485 port cameras.
5.	Turns on/off camera wiper.
6.	Auto focus
7.	Initializes the lens

Note: This feature can vary on different cameras.

Using presets

Presets are predefined locations of a PTZ dome camera that allow you to quickly move the PTZ dome camera to a desired position.

You can only call up the predefined presets. For instance, preset 99 is the “Start auto scan”. If you call the preset 99, the camera starts auto scan function.


These predefined presets cannot be modified. You cannot set up new presets.



Table 9: Predefined preset settings

Special Preset	Function	Special Preset	Function
33	Auto flip	93	Set limit stops manually
34	Back to initial position	94	Remote reboot
35	Call preset tour 1	96	Stop a scan
36	Call preset tour 2	97	Start random scan
37	Call preset tour 3	98	Start frame scan
38	Call preset tour 4	99	Start auto scan
39	IR cut filter in	100	Start tilt scan
40	IR cut filter out	101	Start panorama scan
41	Call shadow tour 1	102	Call preset tour 5
42	Call shadow tour 2	103	Call preset tour 6
43	Call shadow tour 3	104	Call preset tour 7
44	Call shadow tour 4	105	Call preset tour 8
92	Start to set limit stops		


To set a preset:

1. Select a preset number from the preset list.



2. Use the PTZ directional buttons to move the camera to the desired position.
3. Click  to finish the setting of the current preset.
4. You can click  to delete the preset.

To call a preset:



1. Select a defined preset from the list.
2. Click  to call the preset.


Using preset tours

A preset tour is a memorized series of preset function. The camera stays at a step for a set dwell time before moving on to the next step. The steps are defined by presets. A preset tour can be configured with up to 32 presets.

You can configure up to eight preset tours.


To set a preset tour:

1. In the PTZ control panel, click  to enter the tour settings interface.
2. Select a preset tour number from the drop-down list.
3. Click  to enter the adding interface of preset.





4. Configure the preset number, preset tour time, and preset tour speed.

Preset Tour Time	The dwell time. The length of time for which a camera stays at a preset before moving to the next preset.
Preset Tour Speed	The speed the camera moves from one preset to another.

5. Click **OK** to save a preset into the preset tour.
6. Repeat the steps from 3 to 5 to add more presets.
7. Click  to save all the patrol settings.

To call a preset tour:


In the PTZ control panel, select a defined preset tour from the drop-down list and click  to call the preset tour.






Using shadow tours

A shadow tour is a memorized series of pan, tilt, zoom, and preset functions. You can configure up to four shadow tours.

To set a shadow tour:

1. In the PTZ control panel, click  to enter the pattern settings interface.
2. Select a shadow tour number from the list.



3. Click  to enable recording the panning, tilting and zooming actions.
4. Use the PTZ control buttons to move the lens to the desired position after the information:
 - Pan the PTZ dome to the right or left.
 - Tilt the PTZ dome up or down.
 - Zoom in or out.
 - Refocus the lens.
5. Click  to save the settings.

To call a shadow tour:

Select one shadow and click  to call the shadow tour.

Index

3

3D position, 54

8

802.1x parameters, 15

A

Alarm input and outputs, 35

Alarm types

 motion detection, 31

Alarms

 HDD error, 34

 HDD full, 34

 illegal login, 34

 IP address conflicted, 34

 network disconnected, 34

 video loss, 37

Archived files

 playing back, 56

Archiving files

 recorded files, 56

 set up default directories, 9, 10

 snapshots of recorded files, 56

Audio parameters, 17

B

Bandwidth

 optimize, 23

Brightness setup, 19

C

Camera image

 configuring, 18

 day/night, 20

Camera name

 display, 21

Configuration file

 import/export, 50

Contrast setup, 19

D

Date format set up, 21

Day/night setup, 20

DDNS parameters, 14

Default settings

 restore, 49

Display information on-screen

 set up, 21

E

Email parameters, 16

Events

 searching logs, 57

F

Firmware upgrade, 50

FTP parameters, 16

H

Hard drive

 card full, 40

 formatting, 40

I

IP address

 finding IP address of camera, 5

L

Live view

 3D position, 54

 manual recording, 53

 snapshots, 54

 start/stop, 53

Logging on and off, 53

Logs

 information type, 58

 search logs, 57

 viewing logs, 57

M

Motion detection

 configuring, 31

N

- Network
 - define settings, 13
- Network protocol
 - setup, 9, 10
- Network settings
 - overview of local camera parameters, 9, 10
- NTP synchronization, 12

P

- Park actions, 29
- Passwords
 - modifying, 47
- Playback
 - play back recorded files, 56
 - screen, 54
 - searching recorded video, 54
- Port parameters, 14
- Post-recording times
 - description, 41
- PPPoE parameters, 15
- Pre-recording times
 - description, 41
- Privacy masks, 29
- PTZ configurations
 - clear, 31
- PTZ control, 59
- PTZ parameters, 25
 - home position, 25
 - limit camera movement, 26
 - park actions, 29
 - schedule tasks, 27

Q

- QoS parameters, 15

R

- Reboot camera, 51
- Recording
 - defining recoding schedule, 41
 - manual recording, 53
 - playback, 54
 - snapshots from recorded files, 56
 - snapshots in live view mode, 54
- Recording parameters, 17

S

- Saturation setup, 19

- Schedule tasks, 27
- SDHC card
 - card full, 40
 - formatting, 40
 - free space available, 40
- Sharpness setup, 19
- Shutter speed setup, 19
- Snapshots, 38
 - archiving snapshots from recorded files, 56
 - saving during live view mode, 54
- SNMP parameters, 15
- Storage
 - optimize, 23
- Streaming
 - main/sub setup, 9, 10
- System time
 - set up, 12

T

- Tamper-proff alarms, 33
- TCP/IP parameters, 14
- Text
 - adding extra lines of text on screen, 22
- Time format set up, 21
- Tracking moving object, 24
- TruVision Device Finder, 5

U

- UPnP parameters, 16
- User settings, 45
- Users
 - adding new users, 46
 - deleting a user, 47
 - modifying computer ID, 47
 - modifying password, 47
 - types of users, 46

V

- Video loss alarm, 37
- Video parameters, 17
- Video quality, 18

W

- Web browser
 - accessing the camera, 5
 - overview of the interface, 5
- Web browser security level
 - checking, 3