

TruVision<sup>®</sup> Navigator 8

# Unified control for maximum security.

# Intuitive. Powerful. Integrated.

More than just a video management software solution, TruVision Navigator 8 brings Interlogix commercial offerings video, access control, intrusion and networking—together as one integrated security solution. Ideal for small to mid-size applications, the system provides powerful centralized and remote management capabilities, so users can manage every aspect of their Interlogixbased security system, easily and effectively.





interlogix.com/navigator

# Feature rich for improved functionality.

TruVision® Navigator 8 provides added convenience and improved functionality to the TruVision Navigator

#### **User-friendly** interface



TruVision Navigator 8

brings together video monitoring, TruPortal access control, UltraSync® intrusion, and IFS® network switches into one centralized interface. Robust and easy to use, the software's key features include up to 10 video tabs, custom views, dynamic facility/ campus maps, live event monitoring, 360° camera de-warping and an integrated device manager.

# Scalable and compatible

TruVision Navigator 8 is a 64-bit application with

GPU support offering high performance on a properly equipped computer. The application is also a fully scalable solution that can be used as a standalone application, or deployed in a client/server environment. TruVision Navigator 8 also supports integration with other Interlogix hardware platforms such as TruPortal access control, UltraSync intrusion and IFS network switches.



# **High-quality and** affordable

Available with no annual fee and no software maintenance

agreements, TruVision Navigator 8 is an easy-to-use, yet robust, commercial security solution\*.

## **Standard Video Features**

#### **Core TruVision Navigator Features**

- Up to 10 video tabs with video sequencing and custom views Live/playback video viewing from TruVision IP cameras (with
- SD cards)
- TruVision 360°, 180° panoramic and PTZ cameras dewarping
- Camera locations displayed on maps with full camera control
- Embed maps within maps and add relay outputs to maps
- Notifier that displays live color-coded device events
- Real-time event monitoring with live pop-up video
- View, acknowledge and filter all events with the Event Center • Object counting support (reset count, graphical data and
- remove OSD) • Built-in Device Manager provides easy discovery, activation and setup of TruVision devices
- Standalone and client/server architecture
- Admin permissions, management and diagnostics tools
- USB keypad/joystick support
- Supports TruVision thermal cameras
- Improved performance (64-bit app) and supports most GPUs

# **Advanced Video Features**

- Logical device view in device tree
- Logical event filter
- Real-time device bandwidth monitoring
- Server off-line mode client operation when server is offline
- Built-in web browser support for viewing/saving web pages
- Device Manager standard features plus additional tools such as new system device wizard and automatic firmware updates
- Video bookmarking with bookmark manager
- Custom views
- Create a video wall with select TruVision decoders
- Schedule recurring off-site archived video storage

\*Hardware for TruVision Navigator is sold separately. Standard features are included with TruVision Navigator 8. Advanced features may require a one-time licensing fee after the 7-day free trial.

## **Advanced Integration Features**

#### **TruPortal Access Control Integration**

- TruPortal panel discovery on a network
- Multiple panel configuration and management
- Global lockout and reinstate
- Add TruPortal panels and door locations on maps
- Unlocking doors remotely from map or the device tree
- Linking cameras with doors for event monitoring with pop-up video verification
- Easy searching or filtering TruPortal notifications
- Add credentials to multiple panels
- Pop up picture with card read

# **IFS Network Switch Integration**

- Built-in IFS network switch discovery on a network
- IFS network switch log-in and configuration
- View camera names and bandwidth on each port
- Cycle PoE on each port to reboot cameras

#### **UltraSync Intrusion Integration**

- Add intrusion zones and sensors to maps
- Arm/disarm from map or device tree; global arm/disarm
- Link intrusion events to cameras

**7-DAY FREE TRIAL\*** FOR ADVANCED FEATURES



#### interlogix.com

Specifications subject to change without notice. © 2019 United Technologies Corporation. All rights reserved. All trademarks are the property of their respective owners. Interlogix is part of UTC Climate, Controls & Security, a unit of United Technologies Corporation.

