

Ranger Panel ID

Check micro processor 2nd line.

Should be 20- (Panel #) or 20-(Panel #) e.g. 20-8600.

6 Zone panel with 20-8600 will be an 8600

8 Zone panel with 20-8600 will be an 8980

Micro Processor showing 20-8980 is an 8980E

Also and 8980E has a separate Telephone line terminal

An 8900DL has 1 long terminal strip and a Slide Switch at the top left.

An 8900 has 1 long terminal strip and a Slide Switch close to the center of the board

Progression of panels

8800 Chip programmable use Napco pro 410 programmer (We do not have chip)

8900

8900DL

8600

8600E Adds Event Log and Poss Ph line monit

8980

8980E Adds Event Log and Poss Ph line monit

9000

9000E