



## Introduction

This is the *Digia II Release Notes (1058573B)* for the GE Security *Digia II User Manual (1058007B)*. This document includes late-breaking information on this product that did not make it into the manual. Where information differs between the two documents, this document supersedes the manual.

In this release:

<i>Compatible external CD/DVD burners</i> .....	1
<i>Enhancements and workarounds</i> .....	2

## Compatible external CD/DVD burners

The following external CD/DVD burners are compatible with the Digia II:

- Sony DRX-S50U slim DVD-RW drive
- Sony DRX830UL/T DVD-RW external
- Sony DRX820UL external multiformat DVD recorder DRX-820UL
- Philips 16x8x8x/16x6x4x/5x/16x + 48x24x48x external DVD dual drive
- Memorex external 16x16 dual-format DVD-RW and 4x DVD-R dual layer, USB 2.0 and IEEE 1294 connection
- Lightscribe Technology HP dvd740e

## Enhancements and workarounds

The following are enhancements and workarounds that are included with firmware version 1.0.22:

**Optical media.** You must first format the optical media to UDF format before you can archive. When you archive to a DVD+RW or CD+RW, you must manually format the media on a PC with the use of a writer application, such as Nero InCD.

**User accounts.** Digia II allows a maximum of five simultaneous users. The five users include a maximum of four users that can access through the Digia Browser and one that can access through the Digia II.

**Log off.** An operator log off feature maximizes the security of your Digia. The Digia II monitors your activity and so long as you remain within a sixty-second time limit, you only have to enter your passcode once to access any of the Digia II menus. However, if you go beyond this time limit, the system will log you off and require you to reenter your passcode.

**Alarms.** Global alarms is now called group alarms to reflect the alarms that are actually triggered. Previously when a global alarm was triggered, it would set off all other global and enabled alarms; now when a group alarm is triggered, it only triggers other group alarms.

**Freeze and zoom.** Use freeze frame and zoom functions in the *Playback* tab. You could always freeze live video by pressing **Enter** once, and you could zoom in by pressing **Enter** a second time. Now you can activate these features from the *Playback* and *Live* tabs.

**Live video.** Live video is no longer displayed in the *Playback* tab. Previously, in the Digia Browser, the first time an operator selected the *Playback* tab, live video was displayed until the operator began playback. Now, if the operator selects the *Playback* tab, live video does not display.

**Timestamp.** Timestamp controls were moved to the **Record** menu. Previously, any user could update timestamp controls. Now, the function is on the **Record** menu, and only an admin can access it.

**Error message.** The error message for the **Search** and **Export** menus are improved. The error messages in both the **Search** and the **Export** menus are more descriptive so you can easily troubleshoot your unit.

**DigiaPlayer export.** You can now export just the DigiaPlayer. Previously you had to export the DigiaPlayer with video; now you can export the DigiaPlayer through the **Export** menu.

**Search and playback.** We have updated the search and playback response time in the Digia Browser. The structure of the software has been improved so you get quicker video playback and faster search results.

**Indicators.** An hourglass indicator appears at system commands. An hourglass icon will display once the user enters a command, so the user can verify that his request is processing.

**Multilanguage support.** The Digia II now supports English, Czech, German, Danish, Finnish, French, Hungarian, Italian, Dutch, Polish, Portuguese, and Russian.

**Schedule.** The administrator can only change FPS and QL values for *Time Period 1* in the Digia Browser, for the four- and nine-channel models. All other changes must be made from the front panel.

**Display.** Changes made in the **Display** menu from the Digia Browser are not applied. You must make changes to the display settings through the front panel of your Digia II.