

# TruVision Navigator 8.0 SP1 Release Notes

P/N 1073457-EN • REV B • ISS 09JAN19

### Introduction

These are the TruVision Navigator 8.0 SP1 Release Notes with additional information not covered in the user manual. For the latest information on TruVision Navigator 8.0 SP1:

Americas: www.interlogix.com/videoupgrades

EMEA: www.firesecurityproducts.com

Australia: www.interlogix.com.au

#### Overview

This document covers the following:

- Summary of new features and key enhancements
- Summary of bugs fixed

# Summary of new features and key enhancements

#### General

 After a successful user login when the server computer is connected to the internet, TruVision Navigator will try to download the latest Language Pack available from the TruNav Cloud Server.

#### **Device Manager**

 The Add cameras connected to this device check box was added to the Add Device window to add cameras under a recorder in the Navigator panel.

- The Include cameras connected to this recorder check box was added to the Change Password window to change the password(s) for connected cameras.
- Date and time sync support was added for IFS NSxxxx model switches.
  - **Note**: See the *TruVision Navigator Compatibility with IFS Switches Addendum* for further information about supported features.
- The Alarm Host Setup feature was added to the Setup Wizard for New Systems. An alarm host can now be enabled for a specific IP address and port.
- Devices with multiple NICs can now be assigned multiple IP addresses in the Device Manager. Provision of user name and password is required to enable this feature.

#### **Navigator panel**

- Regular camera icons (non-PTZ) used in map markers can now be rotated manually.
- Under the Access Control node, a single user credential can be assigned to multiple TruPortal panels. They can be grouped into one site by using folders to separate sites.

#### Viewer panel

- A Custom Layout Creator was added so that users can create and edit their own custom layouts in a viewer panel.
- Dewarp views from a single camera are limited to a maximum of 31 PTZ views, one Panoramic 180, and one Panoramic 360 view.
- Text strings can be displayed and searched for recorders that support text insertion (TVN22 and TVR45HD).
- Selecting Sync to this video plays back all videos in the Viewer (up to a maximum of nine) at the same current playback time/date of the camera being synced to.

#### **TruVision Navigator standalone player**

 After a successful user login when the server computer is connected to the internet, TruVision Navigator will try to download the latest player available from the TruNav Cloud Server.

## Summary of bugs fixed

#### Access control/TruPortal

- Fixed an issue where an IP address change caused TruPortal to go offline in the Navigator panel.
- Fixed an issue where access control panels were not listed under the Access Control node in the Navigator panel.
- Fixed an issue where online notification is not received when an access control panel is added for the first time with valid credentials.

#### **Device Manager**

- Fixed an issue in Device Manager where the cameras added to a recorder did not appear in the Navigator tab. Cameras connected to the recorder now appear when adding the recorder manually.
- Fixed an issue where the selection of cameras was not restricted in the Device Manager Setup Wizard.

#### General

- Fixed an issue where TruNav.exe was still running in the Task Manager after closing the application.
- Fixed an issue where bi-directional audio support on channel 1 and channel 2 was not supported as on the web browser.
- Sped up slow TruNav login (was up to 10 minutes in large systems).
- Fixed an issue where Logical Event Filtering was not working properly when VCA Alarms > Intrusion Detection was selected.
- Fixed an issue where the CPU usage meter displayed high usage when streaming substream video with **Use GPU** enabled in **Settings** > **Client**.

#### Maps

- Fixed an issue where TruNav was crashing on both client and server machines when configuring maps using icons.
- Fixed an issue where device icons were not visible in the Configure Map window.
- Fixed an issue where show in map and heat map features are not localized in the UI.

#### **Navigator panel**

 Fixed an issue where items under the Intrusion Detection, Network Switches, and Access Control nodes in the Navigator panel did not go offline after an IP address change.

#### Network switches/IFS

- Fixed an issue where IFS switches did not reconnect after a successful switch reboot on both client and server computers.
- Fixed an issue where disconnected IFS switches continue to appear as online and the Statistics window cannot be closed.

#### TruVision Navigator standalone player

- Fixed an issue where pressing the Esc key did not result in bringing up a 4x4 view in full screen.
- Fixed an issue where the slide bar did not move to the place where the user left it but plays from there after live video is played.
- Fixed an issue where the loop icon displays as enabled after the video tiles are closed and reopened again.
- Fixed an issue where video flickering occurred when looping was enabled on one video clip and a clip in a different video tile was selected.
- Fixed the "Snapshots of same Camera exported with Different Timelines are generated only once" error.

#### Upgrade issues

- Fixed an issue where the user cannot log in to Navigator after an upgrade from 7.1 to 8.0 with custom views.
- Fixed an issue where TruNav Server had to be started manually after an upgrade from 8.0.0.8 to 8.0.1.0.
- Fixed an issue where the "Also delete the TruVision Navigator database" message appeared in English instead of French during uninstall in the localized version of TruNav.

#### Viewer panel

- Fixed an issue where dewarp view on Panoramic 180 or Panoramic 360 displayed a black video tile on the third view.
- Fixed an issue where exporting video from the timeline when no recording is present did not generate an error.
- Fixed an issue where local recording cannot be initiated on selected multiple cameras in a video tile.

• Fixed an issue where the Event Monitor was not working with intrusion event reporting alarms.

# **Contacting support**

For help installing, operating, maintaining, and troubleshooting this product, refer to this document and any other documentation provided. If you still have questions, contact us during business hours (Monday through Friday, excluding holidays).

**Note**: Please be ready at the equipment before calling.

North America	
Т	+1 855.286.8889
Е	techsupport@interlogix.com
W	www.interlogix.com/support
Europe, Middle East, and Africa	
W	Select Support/Contact Us at www.firesecurityproducts.com
Australia	
Е	security.tech.support@interlogix.com.au
W	www.interlogix.com.au/support